Product Data and Specifications

Applications

- Low-frequency pressure response measurements
- Low-frequency phase response measurements
- Comparative measurements
- Single and dual-channel measurements

And features

- All microphone sizes from ¼", ¼", ½" and 1"
- Front and rear-vented microphones
- Frequency range¹ from 0.27 Hz 100 Hz
- Calibration levels up to 140 dB (re. 20µPa)

The G.R.A.S. Low-Frequency Calibrator Type 42AE (Fig. 1) permits microphone calibration at frequencies down to 0.01 Hz for both front and rear-vented microphones. It produces a constant sound pressure level down to very low frequencies.

The two-port configuration allows the actual sound pressure in the coupler to be monitored by a reference microphone simultaneously with the microphone under test.

The built-in DC-coupled power amplifier enables the calibration to be used for swept-sine, broadband and step function investigations.

The calibrator can be used for both rear-vented and side-vented microphones. In the case of rear-vented microphones, the Type 42AE can seal the microphone from the preamplifier to obtain the response of the microphone independent of other leaks.

The calibration of microphones in the frequency range below 50 Hz requires a special apparatus which exposes the complete microphone to the pressure variations of the calibration signal, and not just the microphone diaphragm alone. The air equaliza-

Preamplifier- and microphone-dependent. See Fig. 4



Fig. 1 Low-Frequency Calibrator Type 42AE

tion system of a microphone is important for determining the low-frequency response, together with the amplifier of the electronic system.

Air equalization must be fast enough to compensate for changes in altitude and barometric conditions, and slow enough not to affect the response of the microphone at the lowest frequencies. Most measurement microphones will be adjusted to a lower limiting frequency of 1-3 Hz. But 0.1 Hz is not unusual for infra-sound measurements as well as for airbag testing.

Fig. 2 shows its essential features. Around the body of the Type 42AE, which houses the coupler and all its pre-assembled contents, are input and output sockets as well as a green LED.

The numbered items (accessories included with the Type 42AE) are, more or less, common to all measurements setups. The manual describes a series of configurations and measurement setups and specifies in detail what numbered items are required in each case.



Skovlytoften 33 2840 Holte, Denmark Tel +45 45 66 40 46 Fax +45 45 66 40 47 e-mail: gras@gras.dk www.gras.dk



Fig. 2 External features of the Type 42AE. The numbered items are, more or less, common to all measurements setups

Fig. 3 shows a setup for exploiting the full potential of the Type 42AE.

It can be used for comparing the low-frequency phase and pressure response of a pair of matched microphones (A and B) against each other. Alternatively against the known pressure level and phase angle within the coupler of the Type 42AE.

The voltage signal from the Type 42AE is analogous to the acoustic pressure and phase angle within the coupler of the Type 42AE. The relationship between acoustic pressure and voltage output is nominally 1 mV/Pa (the exact value is given on the calibration chart for each individual Type 42AE).

The dual channel Power Module Type 12AR is recommended because it can be used at frequencies down to 0.05 Hz.

The software in the computer/analyser is capable of generating low-frequency signals as well as processing and presenting all required measurement results in terms of SPL/ $\emptyset_{A \text{ or } B}$ vs. SPL/ \emptyset_{coup} and/or SPL/ \emptyset_{A} vs. SPL/ \emptyset_{B} .

Where A and B refer to the two microphones under test, SPL is the Sound Pressure Level and Ø is the phase angle.



Fig. 3 Setup for comparing the low-frequency phase and presure response of a pair of matched microphones (A and B) against each other. Alternatively against the known pressure level and phase angle within the coupler of the Type 42AE.



Fig. 4 Usable frequency ranges depending upon various combinations of microphones (Types 40AG and 40AN) and preamplifiers (Types 26AL and 26HG). The dotted line is at –3 dB

Low-Frequency Calibrator Type 42AE



Fig.5 Overall dimensions of the Type 42AE





Specifications

| Calibration level: Max. level: | Plug:GR1061Retaining ring:GR0745 $2 \times Adapter$ housings:GR0753 $2 \times 2.2 \text{ mm spacers:}$ GR0752 |
|--|---|
| ent - see Fig. 4): Ranging: from: 0.27 Hz (-3 dB) to 100 Hz to: 1.1 Hz (-3 dB) to 100 Hz Signal input: Socket: Socket: BNC Input level: ± 1 V max. Impedance: 1 MQ Signal output (analogous to acoustic pressure in coupler): Socket: Socket: BNC Output level: 1 mV/Pa Impedance: 1 Q Power (provided by included external DC power supply AB0014): Socket (see Fig. 6): Socket (see Fig. 6): 1 A max. Accessories included: Pre-assembled items: Main body Mount for 1" microphones 2 × Contacts for RA0063-S1 Calibrator Heads: | $2 \times 2.2 \text{ mm}$ spacers:GR0/52 $2 \times 3.7 \text{ mm}$ spacers:GR0757 $2 \times \text{Sleeves for } \frac{1}{4''} \text{ preamps.}$ GR1147 $2 \times \text{Inserts for } \frac{1}{4''} \text{ mics.}$ GR1138 $2 \times \text{Inserts for } \frac{1}{4''} \text{ mics.}$ GR1140 $2 \times \text{Adapters for } \frac{1}{4''} \text{ mics.}$ GR1140 $2 \times \text{Adapters for } \frac{1}{4''} \text{ mics.}$ GR1140 $2 \times \text{Adapters for } \frac{1}{4''} \text{ mics.}$ GR1140 $2 \times \text{Adapters for } \frac{1}{4''} \text{ mics.}$ GR1066Screw:GR1516Power supply:AB0014Accessories available:Preamplifiers: $\frac{1}{4''}$ Preamplifier:Type 26AL $\frac{1}{4''}$ Preamplifier:Type 26AL $\frac{1}{4''}$ Preamplifier:Type 26AL $\frac{1}{4''}$ Microphone:Type 40AG $\frac{1}{2''}$ Microphone:Type 40AN1'' Microphone:Type 40ENDuel-channel Power module:Type 12ARDimensions (as shown in Fig 5):Height:Height:117.95 mm (4.64'')Diameter:114.0 mm (4.49'')Weight (as shown in Fig 5):1.58 kg (3\frac{1}{2} \text{ lbs}) |
| For 1/8", 1/4" and 1/2" mics.: | |

G.R.A.S. Sound & Vibration reserves the right to change specifications and accessories without notice



Skovlytoften 33 2840 Holte, Denmark Tel +45 45 66 40 46 Fax +45 45 66 40 47 e-mail: gras@gras.dk www.gras.dk