

Try to mount the finger screw like shown and make sure the mounting base on Type 44AA is stable. If it is not stable please return Type 44AA for repair.



Check that this part is ok.
If the two metal rings can be moved, the part is defective and must be replaced